

Remote Access System for STAM-2 Monitoring Station **STAM-VIEW**

User Manual

stam-view_u_en 10/11

SATEL sp. z o.o. ul. Schuberta 79 80-172 Gdańsk POLAND tel. + 48 58 320 94 00 info@satel.pl www.satel.eu

The SATEL's goal is to continually upgrade the quality of its products, which may result in alterations of their technical specifications and firmware. The current information on the introduced modifications is available on our website. Please visit us at:

http://www.satel.eu

The STAM-VIEW system allows you to get round-the-clock remote access to the system information collected by the STAM-2 alarm monitoring station. Thus the monitoring station subscribers can at any time check the status of the alarm system, and the installers can easily carry out tests and diagnostics of the monitoring. Additionally, the STAM-VIEW system allows viewing the video sequences sent to the monitoring station by the VIVER video alarm verification units. So, the users of STAM-VIEW system can verify themselves whether or not a burglary actually took place.

All you need to use the STAM-VIEW system is just a web browser installed on your computer, smartphone or tablet.

1. System operation

1.1 Login

In order to get access to the STAM-VIEW system, enter in your browser the following address: https://[address of the STAM-VIEW virtual machine]. The address can be entered in the form of an IP address (4 decimal numbers separated by dots) or in the form of a name.

The passwords (access codes) and logins for installers and users are determined by the administrator when they are being added. The system accepts passwords from 4 to 16 characters long. When logging in, you must enter the code from the displayed image in addition to the login and password.

Welcome in rem station	ote access system for STAM-2 m	onitoring	EN PL RU
Login:	Brown_P		
Password:	•••••		
	9F3GRV		
	Click on picture, if it's unreadable		
Security code:	9f3grv		
	Log in		

No activity for 10 minutes will result in logout from the system. Each click to select another tab will restart the countdown.

1.2 Password change

The password assigned to users by the administrator should be changed after the first login to the system. In order to change the password:

- 1. Click on the "Settings" button.
- 2. Enter the old password and the new one (the new password has to be confirmed). Press the "Change password" button to confirm the change made.

SATEL

1.3 Information displayed on logging into the system

Sate1.*	Stam-View - ren for STAM-2 mon	note access system nitoring station		17-01-2012 11:43 EN PL RU 9:53 Log out
My account	Welcome, Armstrong_F		Last log in: 2012-01	-17 11:43:23, Failed: Never
Events				
Partitions	Welcome in r	amoto access system f	or STAM-2 mo	nitoring station
Messages	welcome in r	emote access system in	01 31AM-2 110	intoring station
Settings		Unread messages: 0		
		onread messages. U		
		Events occured since last entry: 8		
		Status		
		Stam-View version	ОК	
		Registered in STAM-2	ОК	
		SSL Certificates	ОК	
		Version	1	
		Version 17012012 (BE	ETA)	

Each time you log in to the system, information is displayed about the time of the last successful and failed login attempts, number of unread messages, number of events that have been received by the monitoring station since the last login, as well as the software version, the status of communication between STAM-VIEW system and monitoring station and the status of SSL certificates. In the event of any inconsistency, information in red color will appear at each of these statuses.

2. Permissions in system

2.1 User permissions

- 1. Selecting language version.
- 2. Viewing assigned sites and related data.

Sate1.*	Stam-View - remote acce for STAM-2 monitoring st	ss system ation	9:27	07-02-2012 09:25 EN PL RU Log out
My account	Welcome, Carmichael L		Last log in: 2012-02-07 09:20	:56, Failed: Never
Events	My account			
Partitions	Hy account			
Messages	Site list			
Settings	Enter site name: Carmichael L	~		
	Name	Carmichael L	<u></u>	
	Telephone number	44 456456456		
	Address	Blue Street 79		
	Information		1.	
	Users	Carmichael L,		
	Installers	No		
	Site state	Disarmed		

- 3. Viewing detailed events received by the monitoring station from sites assigned to the user. The type of events that the user will be able to view shall be defined by the administrator.
- 4. Filtering events in accordance with the following criteria:
 - from a given site,
 - all or selected,
 - for a selected period of time,
 - containing the text entered,
 - with video confirmation.

SATE	ΞL
------	----

				09-02-2012 12:20
Satel*	for STAM-2 monit	EN PL SK		
	Tor STAREZ Monito	aning station	1	9:54 Log out
My account	Welcome, Carmichael L 🖂 (1)		Last log in: 2012-02-09	9 12:14:33, Failed: Never
Events	Events log			
Partitions				
Messages	Y Change filter paramet	ers		
Settings	Date	Туре	Information	Video
	2012-02-07 09:59:00	Information	Edit subscriber: 000000009 - C	
	2012-02-07 09:36:27	Arming	Arm	
	2012-02-07 09:36:21	Disarming	Disarm	
	2012-02-07 09:36:17	Remark	Alarm cancelling	
	2012-02-07 09:36:11	Alarm	Fire/pull station	
	2012-02-07 09:35:59	Arming	Arm	
	2012-02-07 09:35:27	Remark	Callback request	
	2012-02-06 14:03:11	Arming	Arm	
	2012-02-06 14:03:08	Information	End of need for medical suppor	
	2012-02-06 14:03:07	Alarm	Medical support needed	
		<< previous Resu	page 2 from 3 next >> Its per page 10	

Displayed in the window above is an example of event related to video alarm verification (indicated by the \equiv icon). In case of such events, it is possible to preview the recording sent to the monitoring stations by the VIVER unit. Click on the \equiv icon to open a window for playback of the recorded images.



5. Preview of the state of partitions in the assigned sites.

Sate1*	Stam-View for STAM-2	- remote access system monitoring station	09-02-20 EN 9:56 Log	012 12:38 I PL SK J out
My account	Welcome, Carmichae	l L	Last log in: 2012-02-09 12:33:09, Faile	ed: Never
Events	Dartitions			
Partitions	Fartitions			
Messages	Select a site 5.	Carmichael L		
Settings	Number	Description	State	
	01	Garage	Disarmed	
	02	First Floor	Armed	
	03	Cellar	Armed	
	04	Ground Floor	Armed	
		Results per page	10 💌	

Click on the selected partition in the "Partitions" tab to display the time areas assigned to it.

Sate1*	Stam-View	<i>N</i> - remote	access system		09-02-2012 12:40 EN PL SK
	TOP STAM	for STAM-2 monitoring station			Log out
My account	Welcome, Carmich	nael L		Last log in: 2012-02-09 12:3	3:09, Failed: Never
Events	Time area				
Partitions		15			
Messages	Definitions	Exceptions			
Settings	Partition num	ber: 01 , Descri	ption: Garage		
	Arm status	Fr	om	То	
	Disarmed	M	onday, 18:00:00	Tuesday, 06:00:59	
	Armed	Т	uesday, 07:00:00	Tuesday, 17:00:59	
			Bac	:k	

6. Ability to communicate with the installer and administrator using a system of messages.

Sate1*	Stam-View - remote access system for STAM-2 monitoring station	17-01-2012 13:34 EN PL RU 9:29 Log out
My account	Welcome, Armstrong_F	Last log in: 2012-01-17 13:03:50, Failed: Never
Events Partitions	Your messages	
Messages	You have no messages	
Settings	Write a message To: Administrator 💌	
	Send a message	it.

7. Ability to change the password.

Sate1*	Stam-View - remote access system for STAM-2 monitoring station	9:40	7-01-2012 13:03 EN PL RU Log out
My account	Welcome, Armstrong_F	Last log in: 2012-01-17 13:03:	50, Failed: Never
Events	Password change		
Partitions	Password change		
Messages	Old password:		
Settings	New password:		
	Confirm new password:		
	Change password		

2.2 Installer permissions

1. Selection of language version.

2. Viewing the assigned sites and related data.

Sate1.*	Stam-View for STAM-2	- remote acces monitoring sta	ss syster ation	n	9:40	07-02-2012 10:13 EN PL RU Log out
Site list	Welcome, Cameron C				Last log in: 2012-02-07 10:07	7:32, Failed: Never
Event log	Musecount					
Last events	My account					
Partitions	Site list					
Messages	Enter site name:	ETHM-2		~		
Settings	Name	ETHM-2 Carmichael L MICRA		*		
	Telephone num	I		0		
	Address					
	Information			* ETHM	1-2	
	Users		Carmicha	ael L		
	Installers		Cameron	С		
	Site state		Armed			E.

- 3. Viewing detailed events received by the monitoring station from objects assigned to the installer. The type of events that the installer will be able to view shall be defined by the administrator.
- 4. Filtering events in accordance with the following criteria:
 - from a given site,
 - all or selected,
 - for a selected period of time,
 - containing the text entered,
 - with video confirmation.

			07	7-02-2012 10:18	
Sato1*	Stam-View - remote		EN PL RU		
Juici	for STAM-2 monitorir	ng station	9:53	Log out	
Site list	Welcome, Cameron C	Last log in: 20	12-02-07 10:07:3	2, Failed: Never	
Event log	Event details				
Last events	Event details				
Partitions	Date:	2012-02-07 10:17:54			
Messages	Event type:	Arming			
Settings	Identifier:	2222			
	Subscriber:	ETHM-2			
	Service:	No / No			
	Partition:	Partition: Garage Zone: User no. 004			
	Zone:				
	Video preview: No				
	Information:				
	Arm				
		Back			

5. Ability to view the last 20 events received by the monitoring station.

Sate1*	Stam-View - rem for STAM-2 mon	iote access	system	07-02-2012 10: EN PL RI	:15 J
		itering etat	ion i	9:52 Log out	
Site list	Welcome, Cameron C			Last log in: 2012-02-07 10:07:32, Failed: Neve	er
Event log	Last events				
Last events	Lust cronts				
Partitions	Date	Identifier	Code	Description	
Messages	2012-02-07 09:38:10	3333	1 602 01 000	Periodic r	
Settings	2012-02-07 09:36:27	1214	3 401 01 241	Arm	
	2012-02-07 09:36:21	1214	1 401 01 241	Disarm	
	2012-02-07 09:36:17	1214	1 406 01 241	Alarm canc	
	2012-02-07 09:36:11	1214	1 115 01 193	Fire/pull	
	2012-02-07 09:35:59	1214	3 401 01 241	Arm	
	2012-02-07 09:35:27	1214	1 411 01 005	Callback r	
	2012-02-07 09:33:10	3333	1 602 01 000	Periodic r	
	2012-02-07 09:28:11	3333	1 602 01 000	Periodic r	
	2012-02-07 09:23:12	3333	1 602 01 000	Periodic r	
		<< previous R	page 2 from 2 esults per page 10		

- 6. Preview of the state of partitions in the assigned sites.
- 7. Ability to communicate with the administrator as well as the users and installers from the assigned sites using a system of messages.
- 8. Ability to change the password.