



SO-PRG

MIFARE card programmer

so-prg_sii_en 11/23

Quick installation guide

Full manual is available on **www.satel.pl**. Scan the QR code to go to our website and download the manual.



The SO-PRG programmer is used to program the MIFARE® cards (CR SOFT program required). It can also be used to read the numbers of programmed cards and write them to another program (the HID keyboard mode).

Connecting to the computer

Connect the programmer USB port with the computer USB port. Use a USB cable suitable for data transfer. The Windows operating system will automatically detect the device and install appropriate drivers. When the drivers are installed, a virtual serial COM port and a HID-compliant keyboard will be available on the computer.



After the programmer is connected to the computer, all the programmer LED indicators will be flashing for several seconds to indicate start-up.

The HID-compliant keyboard is not available when the programmer is connected with the CR SOFT program.

The declaration of conformity may be consulted at www.satel.pl/ce