

indigo en 03/18

The INDIGO detector enables detection of plate, tempered or laminated glass breaking. This manual applies to the detector with electronics version 1.4 (or newer).

1. Features

- Advanced two-path sound analysis.
- Adjustable detection sensitivity.
- Supply voltage supervision.
- LED indicator.
- Tamper protection against cover removal.

2. Specifications

Supply voltage	12 V DC ±15%
Standby current consumption	12.5 mA
Maximum current consumption	15 mA
Relay contacts rating (resistive load)	40 mA / 16 V DC
Alarm signaling period	
Detection range	up to 6 m
Environmental class according to EN50130-5	
Operating temperature range	10°C+55°C
Maximum humidity	93±3%
Dimensions	48 x 78 x 24 mm
Weight	48 g

3. Description

Glass-break detection

The detector will report an alarm when it detects a low frequency sound (impact) followed by a high frequency sound (glass break) in less than 4 seconds. The alarm is signaled by the alarm output for 2 seconds.

Supply voltage supervision

The detector will report a trouble when the supply voltage drops below 9 V (\pm 5%) for more than 2 seconds. The trouble results in turning on the alarm output. The alarm output remains on as long as the trouble exists.

Electronics board



- 1 terminal block:
 - NC alarm output (NC relay),
 - TMP tamper output (NC),
 - **COM** common ground,
 - +12V power input.
- 2 tamper switch.
- 3 LED ON/OFF pins to enable/disable the LED indicator (jumper installed LED enabled; jumper removed LED disabled).
- 4 microphone.
- 5 red color LED to indicate:
 - detection of low-frequency sound short flash,
 - alarm ON for 2 seconds,
 - low supply voltage ON.
- 6 TEST pins to enable/disable the test mode (jumper installed test mode disabled; jumper removed test mode enabled). In the test mode, the detector reports an alarm when it detects a high frequency sound (glass break sound).
- 7 potentiometer for the adjustment of detection sensitivity (Fig. 2).

4. Selecting a mounting location

- The detector is designed for indoor installation.
- The detector microphone should be directed towards the protected glass, so the best place to mount the detector is the wall opposite the protected glass.
- The distance between the detector and the protected glass must not exceed the detection range (6 m).
- There must be no objects between the detector and the glass.
- The detection range depends on the room acoustics. The shades, curtains, furniture upholstery, acoustic tiles, etc. absorb the sound and adversely affect the detector operating range.
- Do not mount the detector on the same wall as the protected glass.



5. Range test

Check that the detector located in the selected installation location can detect the glassbreak. A temporary 12 V DC power supply will be needed for the test.

- 1. Open the detector enclosure.
- 2. Remove the electronic board.
- 3. Make an opening for the wires in the enclosure base.
- 4. Run wires through the prepared opening to a temporary 12 V DC power source.
- 5. Secure the electronics board.
- 6. Connect the power wires to the +12V and COM terminals.
- 7. Remove the jumper from the TEST pins.
- 8. Close the detector enclosure.
- 9. Put the detector at the planned installation place.
- 10. Power up the detector.
- 11. Place the INDIGO TESTER close to the protected glass and use it to generate a glassbreak sound.
- 12. If the detector reports an alarm, proceed to the next steps. If the detector fails to report an alarm, increase sensitivity or select another installation location and repeat the test.
- 13. Power down the detector.
- 14. Open the detector enclosure.
- 15. Disconnect the power wires.
- 16. Place the jumper on the TEST pins.

6. Installation



Disconnect power before making any electrical connections.

- 1. Remove the electronic board.
- 2. Make the openings for screws in the enclosure base.
- 3. Run wires through the opening prepared earlier.
- 4. Use screws to secure the enclosure base to the mounting surface.

- 5. Secure the electronics board.
- 6. Connect wires to the terminals.
- 7. Close the detector enclosure.

The declaration of conformity may be consulted at www.satel.eu/ce